



POINTS TO PONDER



The bay door opens and the driver starts the vehicle. As the driver waits for the crew to don their gear time is ticking. The crew dons their gear, enters the vehicle and the driver now waits for the crew to apply their seat belts. The driver puts the vehicle in gear and proceeds slowly ahead to only have the bay door come down and strike the top of the fire apparatus.

Did you know?

- Each bay door has a timed “open door” period prior to closing.
- The “open door” periods are typically 60 to 90 seconds long.
- **The remotes that open the doors are able to reset the timer at any point with another push of the remote button.**

Example

Slow Station #1 push out?

Hit the button again to give yourself another 60-90 seconds!

- When the door is in the open position, waving your hand, kicking your leg, or walking through the beam **does not** reset the timer.
- The constant red or red rotating light indicates that the door is in motion.



After a prolonged period of time with the bay door open
PRESS THE REMOTE BUTTON TO RESET THE TIMER
before moving the vehicle!